


# SELSTAD



## Posisjoner anlegg Strandabø



Komponent	Posisjon N	Posisjon Ø	Komponent	Posisjon N	Posisjon Ø
Line 1	62°10.415	5°41.667	Hjørne NV	62°10.549	5°41.942
Line 2	62°10.452	5°41.684	Hjørne NØ	62°10.535	5°42.101
Line 3	62°10.490	5°41.701	Hjørne SØ	62°10.387	5°42.044
Line 4	62°10.526	5°41.717	Hjørne SV	62°10.400	5°41.886
Line 5	62°10.561	5°41.738			
Line 6	62°10.670	5°41.957	Senter Flåte	62°10.348	5°41.949
Line 7	62°10.668	5°41.981	FL1	62°10.291	5°41.630
Line 8	62°10.661	5°42.046	FL2	62°10.315	5°41.626
Line 9	62°10.653	5°42.078	FL3	62°10.479	5°41.706
Line 10	62°10.647	5°42.140	FL4	62°10.462	5°41.862
Line 11	62°10.644	5°42.176	FL5	62°10.446	5°42.132
Line 12	62°10.517	5°42.368	FL6	62°10.418	5°42.310
Line 13	62°10.477	5°42.352	FL7	62°10.267	5°42.253
Line 14	62°10.441	5°42.335	FL8	62°10.245	5°42.186
Line 15	62°10.407	5°42.320			
Line 16	62°10.368	5°42.301			
Line 17	62°10.257	5°42.006			
Line 18	62°10.258	5°42.927			
Line 19	62°10.265	5°41.839			